

FEATURES OF JEPRO MOBILE AUTOSWITCH

JEPRO mobile autoswitch via you can operate the motor and hear in Gujarati, Hindi and English language from anywhere in the world.

When fault occur, system call immediately on your phone and gives information about your faults such as dry run, overload, under voltage and damage conductor of motor.

JEPRO mobile autoswitch can use without simcard like a simple autoswitch.

Whenever motor get power supply, mobile autoswitch ringing to farmer's phone and give information. Also, it informs current of any one phase.

FUNCTION OF EACH KEYPAD OF THE MOBILE FOR CONTROLLING THE MOTOR

0	For information of current	6	Overload set
1	For start the motor	7	Dry run set
2	For stop the motor	8	For enter your mobile number
3	For change password	9	For ON or OFF call facility
4	For reset (fault)	*	For enter your second mobile number
5	Auto / Manual	#	For enter your third mobile number

For start message **PSWD<SPACE>MSG<SPACE>ON**

For stop message **PSWD<SPACE>MSG<SPACE>OFF**

PSWD (9898)

Send message to autoswitch's sim card number